



PRODUCT SAFETY RECALL

YOUNG ONES LIGHT & SOUND GUITAR

Keycode: 55195638

Sold at Target Australia Stores including Target Country and at www.target.com.au from July 2014 – October 2018.



*Colours of toy may vary

Defect: Small part (highlighted above) may detach with applied force.

Hazard: Detached small part may pose a choking risk to small children.

What to do: We recommend you stop using the product and return the product to a Target or Target Country store as soon as possible, where our team members will provide you with a full refund. A receipt is not required to obtain a refund.

Contact: If you require further information, please contact our Customer Support Centre on 1300 753 567 or visit www.target.com.au/help/contact-us

**See www.recalls.gov.au for
Australian Product Recall Information**