

PRODUCT SAFETY RECALL

STARTER COOKSET WITH UTENSILS

Keycode: 58795521

Sold at Target Australia stores including Target Country and at www.target.com.au from March 2016 – March 2019



(4pce cookset with 7 utensils)

Defect: Handle may detach from the cookware.

Hazard: The handles may break on cookware which could result in a serious injury.

What to do: We recommend you stop using the product and return the product to a Target or Target Country store as soon as possible, where our team members will provide you with a full refund. A receipt is not required to obtain a refund.

Contact: If you require further information, please contact our Customer Support Centre on 1300 753 567 or visit www.target.com.au/help/contact-us

**See www.productsafety.gov.au for
Australian Product Recall Information**