

ATTICUS ENTERTAINMENT UNIT

INDOOR USE ONLY · SIMPLE ASSEMBLY REQUIRED · MADE IN CHINA

H 43 CM x W 100 CM x D 35 CM · LOAD LIMIT: 25 KG PER SHELF


MDF with metal frame.

WARNING Do not stand on product. Do not use as a step ladder. Do not use product unless all bolts, screws and knobs are firmly secured. Only use on even surfaces. Failure to follow these warnings could result in serious injury.

CARE INSTRUCTIONS Wipe clean with a soft, damp cloth. Do not use abrasive materials or solvents. Store in a dry place.

ASSEMBLY INSTRUCTIONS

Please read instructions carefully. Remove all wrapping material, staples and packing straps from the carton. See Parts List and Hardware List for guidance. Be sure you have all parts before you start assembling. Place all wooden furniture parts on a clean and flat soft surface, such as carpet or a rug to prevent from being scratched.




PARTS LIST

1.TOP PANEL	:1 PC
2.METAL SIDE FRAME	:2 PCS
3.METAL SUPPORT RAIL	: 3PCS
4.Bottom Metal support Rail	:2PCS
5.Bottom Panel	:1PC

HARDWARE LIST

A. BOLT	:21PCS
B. ALLEN KEY	: 1 PC




FOR ASSEMBLY

- First, check the content to make sure that nothing is missing.
- Sort out the parts and fittings as shown. Assemble product step by step.
- Do not overtighten screws and fittings.
- Re-tighten all screws and fittings periodically.

⚠ WARNING	
Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:	<ul style="list-style-type: none">• Never allow children to climb• Do not stand on product.• Do not use as a step ladder.
<ul style="list-style-type: none">• Unless specifically designed to accommodate, do not set TVs or other heavy object on top of this product.	Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

ASSEMBLY INSTRUCTIONS

STEP 1



(A)



10PCS

(B)




1PC

As the screws are different sizes-Please ensure the correctly fitting screw driver is used to avoid damage to screw head/s. Ensure all screws, nuts, bolts and accessories are securely attached and tight upon completing assembly.

Be cautions if using a power tool as over tightening may damage assembly and hardware!

STEP 2



(A)



6PCS


(B)



1PC

ASSEMBLY INSTRUCTIONS

STEP 3



A




5PCS

B



1PC

STEP 4



**WARNING
TOPPLING
HAZARD**

**PLEASE SECURE YOUR FURNITURE
AND TELEVISIONS TO AVOID SERIOUS
INJURY TO SMALL CHILDREN.**



**SCAN FOR
FURTHER SAFETY
INFORMATION.**

Television sets (slimline and older cathode ray models) present a high risk of toppling if not properly secured. The impact of a TV set falling on a young child can cause serious injury or death. Televisions with a mass of 7kg or more, which are intended to be used freestanding on an Entertainment Unit (or similar furniture item), should be anchored to reduce the risk of the Television toppling.